

# Manual de Armado Silla Directiva Berlín CC



Back Upholstry	Seat Uphdstory	Headrest	Armrest	Gaslift		Base	Caster	Screw sets																						
								<table border="1"> <tr> <td>S1 X 2</td> <td></td> </tr> <tr> <td>M6x20</td> <td></td> </tr> <tr> <td>S2 X4</td> <td></td> </tr> <tr> <td>M6x25</td> <td></td> </tr> <tr> <td>S3 X6</td> <td></td> </tr> <tr> <td>M6x40</td> <td></td> </tr> <tr> <td>S4 X6</td> <td></td> </tr> <tr> <td>M6x16x1.2</td> <td></td> </tr> <tr> <td>S5 X1</td> <td></td> </tr> <tr> <td>M5</td> <td></td> </tr> <tr> <td>S6 X4</td> <td></td> </tr> </table>	S1 X 2		M6x20		S2 X4		M6x25		S3 X6		M6x40		S4 X6		M6x16x1.2		S5 X1		M5		S6 X4	
S1 X 2																														
M6x20																														
S2 X4																														
M6x25																														
S3 X6																														
M6x40																														
S4 X6																														
M6x16x1.2																														
S5 X1																														
M5																														
S6 X4																														
			x2				x5																							

**Step 1**

Nota Importante:  
En caso de que el pistón tenga esta tapita de plástico (El color puede variar) Sólo se retira fácilmente, no necesita forzar, ni herramienta, en caso de no traerlo favor de no forzar ni quitar piezas del pistón. Después de esto puede ensamblar el pistón en el mecanismo.

Tapita de plástico

Take off the plastic cap

**Step 2**

**Step 3**